

mount sockets on bottom of pcb  
(use right angle sockets sma)

